NexGen Burner for Seat Testing

Presented to: International Aircraft Materials Fire Test Working Group – Sao Jose Dos Campos, Brazil

By: Robert Ian Ochs

Date: Wednesday, March 5, 2008



Introduction

- Background
- Initial Measurements
- Planned Work

Background

- A Next-Generation oil burner was developed to provide for an alternative FAA-approved test apparatus to replace the out-of-production Park oil burner for thermal acoustic insulation burnthrough testing
- The burner, called the NexGen (or sonic) burner, was developed and tested vs. the Park oil burner
- The NexGen burner was found to provide similar results
- Multiple NexGen burners were constructed and also provided similar results

Objective

 The objective is to use a NexGen burner to provide similar results to a Park oil burner that is properly calibrated for fire testing of seat cushions

Procedure – Matching Air Velocity

- Measure the inlet velocity on the Park oil burner according to the handbook - 1800±50 fpm
- With the inlet velocity set, measure the exit velocity at the end of the draft tube (~1130 fpm)
- Place the same anemometer at the end of the draft tube on the NexGen burner
- Starting from 0 psig, gradually increase the sonic choke inlet pressure until the same exit velocity is achieved (~1130 fpm)
- Note the inlet pressure (45 psig). This will be the operating pressure for the NexGen burner for seat testing.

Procedure – Matching Fuel Flow Rate

- Install a 2.0 gph-rated CC 80° nozzle into the NexGen burner
- Adjust fuel tank pressure accordingly until 126 mL/min flow rate is achieved (2.0 gph)
- 95 psig fuel pressure measured at the burner gives 126 mL/min for this particular nozzle

Procedure – Matching Calibration

- Perform burner calibration procedures as outlined in the handbook
- Measure flame temperatures with 1/16" thermocouples
- Measure heat flux with 0-25 BTU/ft²*s heat flux transducer
- Adjust burner component configuration to achieve calibration
 - Stator
 - Depth
 - Orientation
 - Turbulator
 - Orientation
 - Ignitor and fuel nozzle depth
- If calibration is still not achieved, work within tolerance limits of air and fuel flowrate to adjust NexGen burner inlet air and fuel pressure
- At this point, still actively working on achieving temperature calibration without resorting to the use of tabs or other flame altering external devices

Work to be Completed

- Perform side by side comparison between a properly calibrated Park oil burner and the NexGen burner
 - Compile a sample set of seat cushions with known fire performance
 - Compare Park, NexGen, as well as with other labs that have run these cushions
- Enter the NexGen burner into a seat round robin

Questions?

