Flame Retardants & Similarity of Material Changes

Richard E. Lyon

Manager, FAA Fire Research

William J. Hughes Technical Center

Atlantic City International Airport, NJ

International Materials Fire Test Working Group Meeting
Atlantic City, New Jersey, USA
October 27, 2014



Flame Retardants & Similarity of Material Changes

- Task Team Would be Industry-Chaired Cost Saving Initiative
- Supported by FAA

FAA Memorandum ANM-115-09 Policy Statement on Flammability Testing of Interior Materials

... the FAA is interested in developing a method so an adhesive used to join two parts can be qualified on its own and used to join any two parts. This would cover many of the items currently in category 2. The FAA is actively examining different adhesives [chemical compositions] and developing such a method. While the specific method is not yet defined, the FAA solicits comment on the approach, which would be an alternative to the methods shown for items 28-32 and 34-41.

FAA Initiatives in Flame Retardant Replacements

- Demonstrate milligram-scale test to measure effectiveness of halogen flame retardant replacements in regulatory fire tests.
- Support similarity testing of cabin materials with substitute flame retardants.

Point of Contact: Rich Lyon, richard.e.lyon@faa.gov; Phone: (609) 485-6076

Acceptable Methods of Compliance

Configurations: Passing more difficult test (OSU > Foam Block > VB > HB) or more flammable configuration/worst case (color, density, thickness, texture, orientation, core cell size/density, etc.) *substantiates* all lesser tests and material configurations of the same chemical composition.

<u>Compositions</u>: If a change in the <u>chemical composition</u> of a certified configuration does not adversely impact the basis for its certification (substantiation), the new configuration is *similar*.

How can we tell if a change in the chemical composition does not adversely impact the results of the certification test (basis) without re-certifying the part?

Similarity

A certified Configuration A is *changed* to Configuration B.

From a certification standpoint, these configurations will be equivalent with regard to safety (similar) if the certification data that substantiates Configuration A also substantiates Configuration B.

In other words A and B are similar if the changes to A, whatever they are, do not impact the original basis for certification.

Flame Retardants and Material Changes

- How can a small change (similarity) be demonstrated?
- Can fire properties of materials predict fire performance of configurations in FAA tests?
- Are fire properties of material combinations additive, i.e.,

$$P_{ij} = P_i + P_j$$


• Or, are there positive/negative interactions too, e.g.,

$$P_{ij} = P_i + P_j \pm \lambda (P_i P_j)^{1/2}$$

1994-1998 Attempt to Evaluate <u>Similarity Of Upholstery Materials</u> in Oil Burner Test Was Inconclusive

- Upholstery: 5 fiber types/blends
- Fire Blockers: 6 fabric types

- Fire Hardened Foams: 8 densities
- Polyurethane foams: 5 densities



 $5 \times 6 \times (8 \text{ or } 5) = 390 \text{ possible combinations}$




Using Microscale Tests to Predict Bench/Full Scale Fire Test Results

Under standard (ASTM D 7309) MCC conditions:

- Flame inhibition by brominated flame retardants in VBB and OSU tests is not captured (working on this).
- Small (milligram) samples may not be representative of bench/full-scale fire behavior (recent example to follow).

FAA Microscale Combustion Calorimeter

- U.S. Patents 6,464,391 & 5,981,290
 - ASTM Standard D7309-13







NON-FLAMING COMBUSTION




MCC Can Measure Flame Inhibition . . .




FAR 25 HRR and Heat Release Capacity







- O Binary Data
- Bin Averages

Predictive Capability of ASTM D 7309 Material Properties in Pass / Fail Fire Tests







MCC Tests of Resveratrol Triazine




Effect of Sample Size on Heat Release Capacity of Resveratol in MCC




No change in decomposition chemistry associated with increase of η_c with sample size



DSC of Resveratrol Triazine Thermoset Shows Strong Exotherm



Combustion of Resveratrol Triazine in MCC



430°C

 $\Delta H_{\rm d} \approx$ -400 J/g (exotherm)

2 HOCN gas (33% of mass)

Solid char


(67% of mass)

$$2 CO_2 + H_2O + N_2$$


 $\Delta H_{\rm c}$ (ΔO_2 , NIST) = 2.4 ±0.1 kJ/g-sample

 $\Delta H_{\rm c}$ (MCC) = 2.3 ±0.5 kJ/g-sample


Probability of Passing FAR 25 HRR Versus Sample Mass



OSU Fire Calorimeter Testing of Resveratrol Triazine / Glass Fabric Lamina



OSU Fire Calorimeter Testing of Resin/Glass Fabric Lamina



Flame Retardants & Material Change Similarity Task Team

Goals of This Meeting:

- Appoint Industry Task Team Leader
- Assign FAA Liaison (Rich Lyon)
- Agree on Scope of Task
- Define Objectives
- Work Plan?