Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT in Vertical Impacts

Presented to: Eighth Triennial International Fire & Cabin Safety Research Conference

By: Amanda Taylor

Date: 27 October 2016




Federal Aviation Administration

Talk Overview

- Basis of the Regulations
- Vertical Impact Standards
- Current ATDs
- New Environments
- THOR-NT
- Motivation
- Test Set-Up
- Instrumentation
- Results



Basis of the Regulations



Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



Federal Aviation Administration

3

Regulations


- Regulations in place to protect occupants in the event of a crash
- Qualification tests of crashworthy seats require two crash tests severity based upon installation



Horizontal Impact Standards


Requirements for **NEW**

- General Aviation Aircraft
- Transport Aircraft
- Rotorcraft



Test-2 Condition

time




•From Above

Horizontal 10° Yaw Orientation		Airplanes Part 23)	Transport	Rotorcraft (Part 27)			
	Pilot	Passenger	(Part 25)				
Gpk (gs)	26	21	16	18.4			
Impact Velocity (f/s)	42	42	44	42			
Onset Time (Tpk)	0.06	0.08	0.09	0.07			



Vertical Impact Standards





Injury/Pass-Fail Criteria $HIC = \left| (t_2 - t_1) \left\{ \frac{1}{(t_2 - t_1)} \int_{t_1}^{t_2} a(t) dt \right\}^{2.5} \right|_{max}$ **Injury Criteria Parameter** Head Injury Criteria (HIC) 1000 1750 lb. (single) Shoulder Harness loads 2000 lb. (dual) 1500 lb. Lumbar Load Fz Femur Load (axial)* 2250 lb. Specified in Part 23.562, 25.562, 27.562, and 29.562

Hybrid II

* (part 25 only)


Measured for Part 572 Subpart B (Hybrid II)



Basis of the Regulations

Dynamic Response Index (DRI)

- Developed by the US Air Force (USAF) to evaluate likelihood of spinal injury during a seat ejection
- Based upon seat acceleration and assumed thin stiff seat bottom cushion
- DRI of 19 is a 9% probability of a detectable spinal injury






Basis of the Regulations

Lumbar Load

- Testing at CAMI showed that DRI was not valid for civilian seating systems that are flexible and lightweight, which makes it difficult to measure seat pan acceleration
- Data allowed for the derivation of a relationship between lumbar load and DRI
- Comparison suggested a lumbar compression load of 1500 lb measured in a 50th percentile male Hybrid II was equivalent to a DRI of 19

PROBABILITY OF SPINAL INJURY





• ATDs for use in certification

- Hybrid II (49 CFR Part 572 Subpart B)
- FAA Hybrid III (deemed equivalent, AIR-100-3-3-2000)





• Hybrid II

- 49CFR Part 572 B
- Instrumentation
 - Accelerometers
 - Head, Pelvis
 - Load Cells
 - Lumbar, Femur






• FAA-Hybrid III

- SAE paper 1999-01-1609
- Accepted for all FAA tests using Hybrid II in AIR-100-3-3-2000
- Instrumentation
 - Accelerometers
 - Head, Pelvis
 - Load Cells
 - Neck, Thorax, Lumbar, Femur, Tibia





- FAA-Hybrid III is predominantly made up of Hybrid III parts except:
 - Hybrid II lumbar spine
 - Hybrid II abdominal insert
 - Hybrid II chest jacket
 - Hybrid II upper leg bone
 - Hybrid II lumbar load cell and pelvic adaptor block
 - Custom thorax/lumbar adaptor





New Environments

 Transport category passenger seats continue to evolve, with the latest development being a partially enclosed (pod) seat that is oriented obliquely with respect to the aircraft centerline, in what is commonly referred to as a "herringbone" arrangement



Delta

Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



New Environments

- In commercial space flight multiple types of vehicles are being proposed
- In 2013 THOR was specified by NASA due to is extensive array of instrumentation



NASA



- Test Device for Human Occupant Restraint (THOR-NT)
 - Loaned from NHTSA
 - Instrumentation (over 100 channels)
 - Accelerometers
 - Head, Thorax, Sternum, Abdomen, Pelvis, Foot
 - Load Cells
 - Face, Neck, Shoulder, Thorax, Pelvis, Femur, Tibia
 - Potentiometers, Tilt sensors, Knee Displacement






- The THOR ATD is under development in the automotive community as a potential replacement for the Hybrid III for frontal crash tests, and is on version -M.
- It has an extensive array of instrumentation, particularly in the thoracic and abdominal regions.






 This instrumentation greatly increases the types of injuries that can be predicted



THOR Users Manual




- After static evaluation, extensive damage to the instrumentation and the lumbar spine element would likely occur during any test that induced lateral or forward flexion at the lumbar
- It was deemed safe to test vertically





ATD Comparison

- The FAA Hybrid III instrumented with a T-12 load cell, to allow direct comparison
 - Hybrid II FAA Hybrid III (Lumbar load cell)
 - THOR-NT FAA Hybrid III (T-12 load cell)
- Loads normalized per AS8049B to the goal acceleration for comparison



Normalized load = <u>recorded load * goal acceleration</u> peak acceleration




- To compare the THOR-NT against other FAA approved ATDs, a rigid fixture pitched up to 60 degrees was utilized to minimize variability
- A 1-inch very firm, rate sensitive cushion was chosen to distribute load on the pelvis while minimizing spinal load amplification






- Tests were carried out on a rigid seat using the deceleration sled
 - 14 G, 44 ft/s impact severity defined in 14 CFR 25.562
 - 19 G, 31 ft/s impact severity defined in 14 CFR 23.562
 - 9 G, 30 ft/s impact severity selected to be approximately proportional to the above conditions






- Wooden representation of rigid seat geometry was used to get 1-G position
 - ATD was lowered into the seat while pressing on the sternum with 20 lb and holding knees up






- Hybrid II and FAA Hybrid III
- Points were measured on the pelvis and head to record nominal pelvis angle and location, as well as torso angle






- Thor-NT flesh is not well coupled to pelvis
- H-Point tool access hole on internal rigid structure of pelvis was used for positioning






- Thor-NT flesh is not well coupled to pelvis
- Alternate points on internal rigid structure of pelvis were used for pelvis angle






- Thigh strap to prevent rebound
- Shim to get in correct position



Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016









- 14 Tests
 - 7 Hybrid II
 - Additional tests were run due to the addition of a foot rest load cell
 - 3 FAA Hybrid III
 - 4 THOR NT
 - Additional test due to pulse failure







Kinematics



Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



HII and FAA Hybrid III Lumbar

ATD	Test Number	Peak G	Goal G	Normalized Lumbar Load (lb)
Hybrid II	A12013	9.9	9	580
Hybrid II	A12031	10.2	9	553
Hybrid II	A12011	14.5	14	909
FAA Hybrid III	A12028	9.9	9	519
Hybrid II	A12032	15.5	14	1040
Hybrid II	A12012	20.0	19	1860
Hybrid II	A12014	19.4	19	1827
Hybrid II	A12033*	18.4	19	1986
FAA Hybrid III	A12030*	18.7	19	1806

* Pulse failed




FAA Hybrid III and THOR-NT T-12

ATD	Test Number	Peak G	Goal G	Normalized T12 (lb)	
FAA Hybrid-III	A12028	9.9	9	423	
THOR-NT	A12015	8.9	9	640	
FAA Hybrid-III	A12029	15.0	14	726	
THOR-NT	A12016	12.8	14	990	
THOR-NT	A12017	14.3	14	1074	
FAA Hybrid-III	A12030	18.7	19	1535	
THOR-NT	A12018	19.1	19	1457	




Lumbar and T-12 loads versus time for 9 G pulse






Lumbar and T-12 loads versus time for 14 G pulse






Lumbar and T-12 loads versus time for 19 G pulse






Sled Acceleration and THOR-NT T-12 Loads versus Time






Hybrid II vs FAA Hybrid III





Hybrid II vs FAA Hybrid III



Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



Hybrid II vs FAA Hybrid III


- Hybrid II was stiffer than the FAA Hybrid III
- Relative error between the lumbar loads
 - -9G = 8%
 - 14 G = 10%
 - 19 G = 4%
- Error within 10%
- Small sample size

Relative Error = FAA Hybrid III Lumbar Load – Hybrid II Lumbar Load

Hybrid II Lumbar Load




T-12 versus Lumbar Load for FAA Hybrid III



Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



Load vs Sled Acceleration for Thor and FAA Hybrid III





Discussion

- Direct injury evaluation was originally made with the Hybrid II
- Using DRI and lumbar load a limit of 1500 Ibs is a 5% risk of a detectable spinal injury
- Hybrid II was stiffer than the FAA Hybrid III
- Relative error between the Hybrid II and FAA Hybrid III was 10% or less supporting equivalency



Discussion

- Hybrid II and FAA Hybrid III lumbar load did not exhibit a linear trend with respect to sled acceleration suggesting the ATD is rate sensitive
- Same spinal unit for both Hybrid ATDs, currently no dynamic calibration exists, but would be appropriate to ensure consistent results for certification
- No T-12 limit has been established
- For FAA Hybrid III T-12 and Lumbar exhibited linear relationship
- FAA Hybrid III T-12 was less than the THOR-NT T-12, at the lower loading rates, but higher at 19 G



Conclusion

- Based on the tests run in this series, the THOR-NT would not be considered an equivalent ATD to the Hybrid II for vertical testing
- Thor does not exhibit same rate sensitivity as FAA Hybrid III which precludes a simple transfer function between them.
- Additional research is needed to determine appropriate lower thoracic spine injury metrics



Questions?

Vertical Comparison of the Hybrid II, FAA Hybrid III, and THOR-NT 27 October 2016



References

- Payne, P. R. 1975. Spinal injury in the crash environment. Payne, Inc., Annapolis, Md. 26 p. Saczalski, K., Singley, G. T., 111, Pilkey, W. D., and Huston, R. L., eds. Aircraft Crashworthiness. Charlottesville, University Press of Virginia, 1975. Pp. 273-298. UMTRI-34179 A10
- Little, J. D. and Annett, M. S. "The Evaluation of a Test Device for Human Occupant Restraint (THOR) Under vertical Loading Conditions: Part 1 – Experimental Setup and Results," The 69th Annual American Helicopter Society Forum and Technology Display; Phoenix, Az, May 21-23, 2013.
- Gowdy, V., DeWeese, R., Beebe, M., Wade, B. et al., "A Lumbar Spine Modification to the Hybrid III ATD For Aircraft Seat Tests," SAE Technical Paper 1999-01-1609, 1999, doi:10.4271/1999-01-1609
- Department of Transportation. 2000. Federal Aviation Administration, Information: Use of the Hybrid III Anthropomorphic Test Dummy in Seat Dynamic Testing. Washington, DC. Federal Aviation Administration, Memorandum, AIR-100-3-3-200, March.
- Haffner M., Eppinger R., Rangarajan N., Shams T., Artis M., Beach D. "Foundations and Elements of the NHTSA THOR Alpha ATD Design," Proceedings of the 17th International Technical Conference on the Enhanced Safety of Vehicles, 2001
- Polanco, M.A., and Littell, J.D., "Vertical Drop Testing and Simulation of Anthropomorphic Test Devices," Proceedings of the American Helicopter Society 67th Annual Forum, Virginia Beach, VA, May 3-5, 2011.
- Putnam, J., Untaroiu, C., Littell, J., & Annett, M."Validation and sensitivity analysis of a finite element model of THOR-NT ATD for injury prediction under vertical impact loading." AHS International 69th Annual Forum. May 21, 2013.

