# HEAT RELEASE RATE Updates

**2015 October Materials Meeting Atlantic City, NJ** 

Materials Working Group
Michael Burns, FAA Tech Center
October, 2015



### **AGENDA**

- HR2: Design of Experiment (DOE)
  Draft Test Plan
- OSU: Airflow Split Round Robin Test Plan
- Next



### DOE Draft Test Plan Concept

- Randomize 4 main parameters
- Initially use Material Simulator Test to study impacts on data

Parameter	DESCRIPTION	Min.	Avg.	Max.
System Air Flow rates	SCFM	19	20	21
Heat Flux (W/cm <sup>2</sup> )	Center	3.60	3.65	3.70
Llaman Dilat	Air (L/min)	0.8	1.0	1.2
Upper Pilot	Methane (L/min)	1.3	1.5	1.7

#### **Data collection:**

#### Software

- Time
- Thermopile voltage (Real time)
- Thermopile voltage (15 minute Running average)
- Center Heat flux (Real Time)
- Center Heat flux (60 second Running average)
- Inlet air Flow (SCFM)
- Inlet air temperature



#### **Data collection:**

#### Manually recorded periodically

- Time
- Ambient Conditions
  - Room temp
  - Barometric Pressure
  - % Relative Humidity
- Inlet air % Relative Humidity



#### **Data collection:**

Manually recorded periodically (Continued)

- % Power to Upper globars
- % Power to Lower globars
- Methane flow rate upper pilot burner
- Methane flow rate to lower pilot burner
- Air flow rate to upper pilot burner
- Air flow rate to lower pilot burner



Run Order	Series	Data Point	Airflow (SCFM)	Center Heat Flux (W/cm2)	Upper Pilot Flame Methane (L/min)	Upper Pilot Flame Air (L/min)
1	1	PRE	20	3.65	1.5	1.0
2	1	2	19	3.60	1.3	0.8
3	1	3	19	3.60	1.3	1.2
4	1	4	19	3.60	1.7	1.2
5	1	5	19	3.60	1.7	0.8
6	1	POST	20	3.65	1.5	1.0
7	2	PRE	20	3.65	1.5	1.0
8	2	2	19	3.70	1.3	0.8
9	2	3	19	3.70	1.3	1.2
10	2	4	19	3.70	1.7	1.2
11	2	5	19	3.70	1.7	0.8
12	2	POST	20	3.65	1.5	1.0
13	3	PRE	20	3.65	1.5	1.0
14	3	2	21	3.60	1.3	0.8
15	3	3	21	3.60	1.3	1.2
16	3	4	21	3.60	1.7	1.2
17	3	5	21	3.60	1.7	0.8
18	3	POST	20	3.65	1.5	1.0
19	4	PRE	20	3.65	1.5	1.0
20	4	2	21	3.70	1.3	0.8
21	4	3	21	3.70	1.3	1.2
22	4	4	21	3.70	1.7	1.2
23	4	5	21	3.70	1.7	0.8
24	4	POST	20	3.65	1.5	1.0



### **Daily Calibration Routine**

- Insert HFG calibration assembly in machine and set airflow and heat flux parameters at nominal values (See data point PRE).
- Allow machine to reach equilibrium (workbook, section 2.10).
- Remove HFG calibration apparatus and close all doors.
- Conduct Methane gas calibration and record all values.



#### **Daily PRE Test Routine (Nominal Parameters)**

- Light pilot burners and set as per data point PRE.
- Allow system to stabilize then record 5 minutes of data.
- Turn OFF upper and lower pilot burners.

#### **Daily TEST Routine**

• Insert HFG calibration assembly in machine and set air flow and heat flux parameters as per data point #2 for scheduled test day.



### **Daily TEST Routine (Continued)**

- Allow system to reach equilibrium.
- Remove the HFG calibration assembly.
- Light pilot burners and set as per data point #2 for scheduled test day.
- Allow system to stabilize then record 5 minutes of data.

### **Daily TEST Routine (Continued)**

- Systematically change inputs per Test Matrix, recording the time of each change.
- Allow system to reach equilibrium at each step before recording 5 minutes of data.
- Turn OFF upper and lower pilot burners.



### **Daily POST Test Routine (Nominal Parameters)**

- Insert HFG calibration assembly in machine and set airflow and heat flux parameters at nominal values (See data point POST).
- Allow system to reach equilibrium.
- Remove the HFG calibration assembly.
- Light pilot burners and set as per data point POST.

#### **Daily POST Test Routine (Continued)**

- Allow system to stabilize then record 5 minutes of data.
- Turn OFF upper and lower pilot burners.
- Repeat steps on following day until matrix is complete.

### **Material or Simulator Testing?**

TBD



### MATERIAL SIMULATOR TEST

- Lower Pilot (Nominal Parameters)
  - Air set to  $1.0 \pm 0.2$  L/min
  - Methane set to  $120 \pm 5$  mL/min
- Upper Pilot (Nominal Parameters Initially)
  - Air set to  $1.0 \pm 0.2$  L/min
  - Methane set via software program (1.5 L/min)
- Empty Sample Holder Inserted in Holding Chamber




### MATERIAL SIMULATOR TEST

(Empty Sample Holder Inserted in Holding Chamber for 1 minute)

- START TEST (60 Seconds in Holding Chamber)
- 0:00:00 Flow rate 1.5 L/min for 15 seconds
- 0:00:15 Set flow rate to 4 L/min for 45 seconds
- 0:00:60 Set flow rate to 2 L/min for 60 seconds
- 0:02:00 Set flow rate to 1.5 L/min for 3 minutes
- 0:05:00 End Test



#### **Material Simulator Test Using a Mass Flow Meter (Methane Gas)**




#### **HR2 Simulator Test Data**

RUN	PHRR	TTP	THR
1	68	57	65
2	66	57	63
3	68	60	64
4	67	59	65
5	67	59	63
6	67	61	64
AVG	67	59	64
STDEV	0.6	1.6	0.8
% STDEV	0.9%	2.7%	1.2%

#### **OSU Simulator Test Data**

PHRR	TTP	THR
66	64	64
65	59	65
68	62	64
67	58	65
69	64	66
67	61	65
67	61	65
1.3	2.5	0.8
2.0%	4.1%	1.3%
















Airflow Split Data

- Install Airflow Measuring Equipment (No plug; Doors Closed)
- Measure and record Total Airflow
- Measure and record Bypass Airflow (Plug Inserted; Doors Open)

Pressure Data

- Install lower plenum probe; measure and record (No plug; Doors Closed)
- Install interspace area pressure probe; measure and record (No plug; Doors Closed)

Data Submittal

- Submit data to Tech Center for review
- When instructed, forward equipment to next facility



Heat Flux

- Set Center Heat Flux
- Verify 4-corner uniformity
- Record baseline millivolt reading (No Pilot flames lit)

Calibration

• Conduct methane gas calibration

Testing

- Record baseline millivolt Reading (Both upper and lower pilot lit)
- Test coupons per heat release requirements of FAR 25.853 Appendix F (ONLY POSITIVE HEAT RELEASE VALUES RECORDED).
- Submit **RAW HEAT RELEASE RATE DATA** to FAA Technical Center (No thermopile millivolt data please)



### **NEXT**

- Complete DOE Test Plan (Task Group input)
- Follow-on Material Testing (DOE)
- Begin Airflow Measurement Round Robin Testing
- <u>Announcement</u>: 2016 NBS Smoke Density Round Robin (Spring / Summer Timeframe)

### **QUESTIONS?**

"The only place success comes before work is in the dictionary"

Vince Lombardi

